



## TOURNA BALLPORT ASSEMBLY

**Required Tools:** Phillips Screwdriver

**Estimated Time:** 10 minutes

**OPTIONAL WHEEL ASSEMBLY: (FOR BALLPORT DELUXE WITH WHEELS)**

**IMPORTANT:** If you have WHEELS, attach the wheels prior to assembling the unit

1. Pick a side panel with the Ballport name on the side
2. Line up the holes of the wheel to the holes on the corner of the panel
3. Screw > Washer > Wheel > Hex Nut (Hex Nut is seated on the inside of the panel)

### BALLPORT ASSEMBLY:

1. Pick a side panel with the Ballport name on the side and one end panel. Insert and push together
2. Pick another end panel. Insert and push together
3. Place two top rods into the sliding grooves
4. Place two bottom rods into the rod projections
5. Insert the remaining end panel with Ballport name on the side and push together
6. Use 8 screws to secure the top and bottom corners of the unit
7. Insert the handles into the holes on the end panels. Handles should run vertically through the snaps
8. Place handle end cap with two holes over the handles. Line up holes, insert screws, and tighten. Repeat on the other side.

### Parts List:

- 2 Side Panels
- 2 End Panels
- 2 Handles
- 2 Handle End Caps
- 4 Fiberglass Rods
- 12 ½" screws

### Optional Wheels:

- 2 wheels
- 8 screws
- 8 washers
- 8 hex nuts

